

Body work, bracketry

			POA
<i>Specialized coachwork</i>	Wooden body frames, complete or as needed		
	Panel work, complete or as needed		POA
	Fenders, fender valances		POA
	Tool boxes, decorative wood or metal, above running boards		POA
	Tool boxes, metal, below running boards		POA
	Paint work, complete or as needed		POA
VBR - L102	Door latch, unfinished	\$	550.00
VBR - H100	Door hinge, 3-1/2", brass	\$	235.00
VBR - H101	Door hinge, 4-1/2", brass	\$	242.00
VBD - B101	Bonnet catch assembly, consists of E 475 - bonnet fastener E 3645 - cover for rear bonet catch U 730 - eye bolt U 352 - spring guide U 353 - washer for bonnet catch U 1449 - catch for bonnet		POA
VBD - B110	Bonnet side panels, louvered	\$	998.50
VBD - H105	Bonnet hinges, nickel silver, set	\$	1,600.00
VBD - H105b	Bonnet hinges, brass, set	\$	1,600.00
U 686/	Tongue for bonnet	1100-2600, A-G, H-U	\$ 16.00
VBD - V102	Cowl vent, nickel silver, w/internal reinforcing & solid nickel trim piece	\$	1,480.00
VBD - B100	Hood bows, wood		POA

Dash & Gauge

VEN - G112	Gauge ferrules, oil or fuel, brass	\$	14.50
S 729b	Nuts, rotheram, 5/16" brass, for gauge	\$	5.90
VEN - G113	Gauge ferrules, oil or fuel, nickel plated	\$	16.50
S 729c	Nuts, rother, 5/16" nickel plated for gauge	\$	7.40
VEN - G114	Gauge, fuel pressure, nickel/brass	1911-1915	\$ 565.00
VEN - G115	Gauge, oil	1911-1915	\$ 565.00
VEN - P139	Pulley, speedo drive	pre 1600	\$ 375.00
VEN - C151	Speedo cable, inner, per foot		\$ 2.30
VEN - C152	Speedo cable, outer, per foot		\$ 2.40
VEN - T163	Thermostat, in line 160		\$ 57.60